

# 目 录

About This Manual

Common Operations

Account Registration

Login

Logout

Home

Interface Description

Viewing Plant Information

Plant Information Introduction

Viewing Device Information

Plant Configuration

Plant Sharing

Querying Plant

Fault

Interface Description

Querying Faults

Viewing Fault Details

Closing Fault

Report

Interface Description

Custom Report

Statistics Report

Report Push

Curve

Interface Description

Viewing Curve

Saving Query Template

Selecting Query Template

Settings

Interface Description

Querying Device

Initial Grid Connection

Command Line Parameters Setup	
General Parameter Setting	
Advanced Parameter Setting	
Viewing History Task	
Firmware Update	
Interface Description	
Firmware Update	
Viewing Task History	
String IV Curve Scan and Diagnosis	
Interface Description	
Parameter Setting	
Advanced Settings	
IV Intelligent Curve	
Viewing Task History	
Failure Plan	
Interface Description	
Querying Plan Information	
Adding Plan Information	
Deleting Plan Information in Batch	
Modifying Plan Information	
Deleting Plan Information	
Appendix	
Manual Description	
Contact SUNGROW	

# About This Manual

## About This Manual

---

### Target Group

This manual is intended for distributors, installers, and end users of residential PV plant, energy storage system, and commercial PV plant.

### Symbols

Additional information, emphasized contents or tips that may be helpful, e.g. to help you solve problems or save time.

### System Requirements

Item	Requirement
Browser	Chrome 60 or later (recommended), Safari 10 or later, Firefox 60 or later, and IE11 or later
Resolution	1920 * 1080 (recommended) / 1366 * 768 (supported)

### Expression Explanation

Type	Example
Select certain element or menu	Select "Plant Overview"
Select several elements or menus	Select "All plants -> Plant unit"

### Intended Use

This manual is intended to guide users in operating and managing iSolarCloud.

This manual is prepared based on the version V1.4.6.20191210.  
Screenshots are for reference only, and actual interfaces may differ.



# Common Operations

# Account Registration

## Account Registration

---

This section describes how to register an iSolarCloud account.

### Prerequisites

The iSolarCloud operates normally and the network between the computer and the server is normal.

The service address is set to “European server” or “International server”.


### Introduction

The account distinguishes two user groups, end user and distributor/installer.

The end user can view plant information, create plants, set parameters, share plants, etc.

The distributor/installer can help the end user to create plants, manage, install, or maintain plants, and manage organizations as well as users.

### Procedure

1. Enter the specified URL <https://www.isolarcloud.com>.
2. Click the icon  in the upper right corner to switch languages.
3. Click “Register” to enter the registration interface.
4. Select “end user” or “distributor/installer” to enter the corresponding interface.
5. Enter the registration information, including server address, e-mail address, verification code, password, confirm password, country (region), and time zone. The distributor/installer further has the permission to fill in the company name and the code of upper level distributor/installer.

- European users and African users select "European server". Users other than mainland China users, European users and African users select "International server".

- At present, users selecting "Chinese server" cannot register accounts.

- The code of upper level distributor/installer can be obtained from the upper-level distributor/installer. Only when your organization belongs to the upper-level distributor/installer organization, can you fill in the corresponding the code.

- When the country (region) is set to Brazil or Mexico, the field "Code

of upper level distributor/installer" must be filled in.

6.Tick "Accept privacy protocol" and click "Register", to finish the registration operation.

# Login

## Login

---

This section describes how the end user or distributor/installer logs into the iSolarCloud management system.


### Prerequisites


The user has got the account and password.

The iSolarCloud operates normally and the network between the computer and the server is normal.

### Procedure

1. Enter the specified URL <https://www.isolarcloud.com> in the browser address bar.

2. Click the icon  in the upper right corner to switch languages.

3. The system automatically switches to the corresponding server address according to the user IP; or users can click the button  to manually switch the server address. Mainland China users select "Chinese server", European and African users select "European server", the other users select "International server".

4. Enter the username and password and click "Login".

For the convenience of subsequent login, the users can select "Remember me".

# Logout

## Logout

---

This section describes how the end user or distributor/installer logs out of the iSolarCloud management system.

### **Prerequisites**

The user has logged into the iSolarCloud management system.

### **Procedure**

Click the button “Logout” in the lower left corner of the home page to log out of the iSolarCloud management system.

# Home

# Interface Description

## Interface Description

Click the menu “Home” to enter the corresponding interface, on which you can view plant information, share plants, etc.



1. Menu Bar
2. Help
3. Personal center
4. Plant query bar
5. Plant information List
6. Plant operation Bar

### Menu bar

The menu bar displays main function categories of the iSolarCloud. Users can switch to the corresponding interface of different functions and perform related operations.

Function page	Description	
Home	Display plant list. View detailed plant information. Share or delete plants.	
Fault	View fault information of plant devices.	
Report	View plant statistics reports (daily report, weekly report, monthly report, annual report and overall report); create self-defined reports.	
Curve	View plant power generation curve.	
Advanced	Settings	Set initial grid connection parameters of plant devices.
	Firmware update	Upgrade plant software device.
	String IV curve scan and diagnosis	Scan component I-V curve, diagnose component working status, and automatically locate faulty components.
	Failure plan	Set plant plan manner.

Only the distributor/installer has the permission of firmware update and string IV curve scan and diagnosis.

## Help

Item	Description
About	Click "About" to view the software version, terms of service, and privacy policy.
User manual	Click "User manual" to view the corresponding user manual.
Help center	Click "Help center" to view FAQs.

## Personal center

Item	Description	
Me	General information	Click "Me" to enter the user information interface, on which you can bind an e-mail address, add a contact number, select country (region), and set time zone. The distributor/installer can view his organization code, but the end user does not have organization code.
	Organization code	The distributor/installer can view and modify the superior organization information and can be managed by the superior distributor/installer. The end user has no permission to view or modify the superior organization information.
	Account and security	Click "Account and security" to bind a phone number or email address for retrieving password. In addition, you can change the password.
	Privacy	You can determine whether to receive notifications.
	General settings	You can switch the language, theme color, background color, radiation unit, and temperature unit.
Background management		If you have the background management permission, click "Background management" to enter the corresponding interface.

## Plant query bar

Users can search for desired plants by setting corresponding conditions.

## Plant information list

Display all plants of the current user and plants shared by others.

## Plant operation bar

You can share and delete plants.

Only the end user can share plants, and the distributor/installer does not have the sharing permission but can receive shared plants.






# Viewing Plant Information

## Viewing Plant Information

In the plant information list area, you can view plant information and device information as well as configure plants.

This area displays plant state and other basic information.

Description of plant information parameters

Parameter	Description
Plant state	Running and communication states of the power plant normal running  , fault  , alarm  , off-line  , connected 
Plant name	User self-defined name
Plant type	The type is determined based on application scenario and it can be set on the “Plant configuration” interface.
Power installed	Installed power of the plant which can be edited on the “Plant configuration” interface.
Real-time power	Real-time output power of the plant
Yield today	Accumulative power yield of the day

# Plant Information Introduction

## Plant Information Introduction

Parameters displayed may vary with plant types, and actual interfaces prevail.

Description is given by using residential energy storage plant as an example.

1. Click the plant name on the “Home” page to enter the corresponding plant information interface.
2. Click “Overview” on the menu bar to view detailed plant information.

### Viewing basic plant information

Basic plant information includes yield today, yield this month, total yield, CO2 reduction, etc.

### Viewing power flow diagram

You can view information such as real-time power, feed-in power, load power, and battery charging/discharging power.

The power flow diagram of the energy storage system is as follows:






The line with an arrow indicates energy flow between connected devices, and the arrow pointing indicates energy flow direction.

Gray line indicates that the connected devices are in off-line state.

### Viewing and exporting plant data

Plant data can be viewed and exported based on time segment “Day”, “Month”, “Year”, and “Total”.

1. Click “Day”, “Month”, “Year”, or “Total” to select the desired period.
2. Perform the following operations according to actual conditions.
  - Click the icons  and  in the upper right corner to display the data in chart form and table form respectively.
  - Click the icon  in the upper right corner to export the plant data, where the exported file is in .xlsx format by default.




# Viewing Device Information

## Viewing Device Information

---

Select “Device information” on the menu bar to enter the device information interface, on which you can view basic device information and alarm information.

### Querying device






1. Enter device name and select device type and device state.
2. Click  to view the corresponding devices.

### Viewing device information

All devices in the plant are displayed in the tab form. Click the tab to view corresponding device information. You can view the basic device information, device alarm information, power curve, etc.

#### Viewing basic device information

The basic device information includes real-time data such as voltage, current, power, temperature and power generation, and information such as device state, device type, serial number, and manufacturer.


1. Click device name, and you will enter “Device basic info” interface by default.
2. Click the icon  to select time segment and time interval, and click . In this way, you can view history information.
3. Perform the following operations according to actual conditions.
  - Click the icon  to export the parameter information in the .PNG format.
  - Click the icon  to refresh the interface information.
  - Click the icon  to change the curve into report.
  - Click “Save table data” to export the parameter information to the local.

#### Viewing device alarm (open)

View the list of alarms not closed.

1. Click device name, and you will enter “Device basic info” interface by default.
2. Click “Device alarm (open)” to enter the corresponding interface.

3. Select time segment, enter fault name, and select “Alarm level” and “Alarm processing state”.

4. Click  to view the corresponding faults.


### Viewing device alarm (closed)

View the list of history alarms closed.

1. Click device name, and you will enter “Device basic info” interface by default.

2. Click “Device alarm (closed)” to enter the corresponding interface.

3. Select time segment, enter fault name, and select “Alarm level”.


4. Click  to view the corresponding faults.


### Viewing chart

View power generation information displayed in the chart.




1. Click device name, and you will enter “Device basic info” interface by default.

2. Click “Chart” to enter the corresponding interface.

3. Select time segment and click the icon  to select the time interval. The power generation statistical period can be set to 5 minutes, 15 minutes, or 60 minutes.

4. Click  to view the corresponding curve.

5. Perform the following operations according to actual conditions.

- Click the icon  to export the parameter information in the .PNG format.
- Click the icon  to refresh the interface information.
- Click the icon  to change the curve into report.
- Click “Save table data” to export the parameter information to the local.

## Repair

This section describes how to repair devices.

### Procedure

1. Click device name, and you will enter “Device basic info” interface by default.

2. Click “Repair” at the bottom of the interface to enter the corresponding interface.

3. Fill in fault information.

Parameter	Description
Fault name	Includes two types fault and warning
Processing time	Estimated time for processing the fault. Includes emergency, 1 hour, 8 hours, 1 day, 3 days, 3 days above
Source	Cause of the fault Includes manual inspection, routine maintenance, interval test, device maintenance, device rebuilding, system note, and other sources

4.Optionally, fill in fault details and upload fault picture.

5.Click “Repair” to upload the fault. You can view the repair information on the “Fault” interface.

# Plant Configuration

## Plant Configuration

This section describes how to modify plant information and how to set the tariff.

### Modifying plant information


This section describes how to edit basic plant information.


#### Prerequisites

The user has the permission of editing plant information.


#### Procedure

1. Click "Plant configuration" -> "Plant" to enter the corresponding interface.
2. Fill in the basic plant information.

Parameter	Description
Plant name*	User self-defined name
Owner's email	The e-mail address of the end user, used for receiving fault and alarm notification messages.
Power installed*	Plant installed power Click "Setting" and a setting window pops up. Click  to enter the power value, in kWp. Click "Confirm".
Plant type	It can be set to "Commercial PV", "Residential (PV)", or "Residential (Storage)".
Grid-connection type	It can be set to "Self-consumption, surplus electricity feeds to grid", "Zero Export", "100 % feed-in", or "Off-grid".
Location	The system automatically obtains the longitude, latitude and detailed address of the plant. Users can manually modify longitude, latitude, and detailed address of the plant.
Image	Click "Image upload" to select a local image and upload it.
Country (region)	Country (region) where the plant is located at.

Time zone	Time zone of the plant
Time of connection	Time at which iSolarCloud starts to monitor the plant
Grid-connection date	It is the time of creating the plant by default. Click the icon  to modify the grid-connection time.
Plant delivery address and zip	Delivery address and zip code for spare parts
Distributor/installer organization code	-

Note: \* indicates fields that must be filled in.

- The end user assigns the distributor/installer to manage the plant, and fills in the distributor/installer organization code which can be obtained from the corresponding distributor/installer.
- If the end user changes another distributor/installer to manage the plant, click the button  to modify the organization code, so that the plant will be managed by the another distributor/installer.
- The distributor/installer can change the organization code to transfer the plant to another distributor/installer for management.

3.Click “Save”.

## Tariff

The tariff is used to calculate revenue.

This section describes how to set a specified tariff and TOU tariff.

### Prerequisites

The user has the permission of setting the tariff.

### Procedure

1.Click “Plant configuration”-> “Tariff” to enter the corresponding interface.

2.Set the tariff to a specific value or set the TOU tariff.

- Setting the tariff to a specific value

Specific value: the tariff is the same for all time segments.

1.Select a charging unit.

2. Enter the tariff.

3. Click "Save".

- Setting TOU tariff

TOU tariff: the tariff is different at different time segment.

1. Select a charging unit.

2. Enable "TOU tariff".


3. Fill in start time, end time, and price.

4. Optionally, click "Add" to set time segment and tariff.

5. Optionally, repeat the foregoing step to set TOU tariff for multiple time segments within a day.

6. Fill in "Price in other time period".

7. Click "Save".

Click the icon  to delete the corresponding setting item.

TOU tariff should cover 24 hours and be different in each time segment.

# Plant Sharing

## Plant Sharing

---

The plant list includes plants of the end user and plants shared by other end users.

### Sharing Plant


End user can assign plants to other end users or distributor/installer for management.

### Prerequisites

Only the end user can share plants, and the distributor/installer does not have the sharing permission but can receive shared plants.

The end user has plants.

### Procedure

1. Click the icon  on the operation bar, to enter the sharing interface.
2. Click “ADD Share”, and the ADD Share window pops up.
3. Fill in the “Shared email” select sharing authority (Read Only or Management).

Description of sharing permission

Permission	Description
Read only	Users can only view data of the plant.
Management	Users can manage the plant but cannot delete the plant.

4. Click “Confirm” to finishing the sharing operation.

Plants can be shared to at most 6 users who have the management permission, but the number of users who can view plant information is not limited.


The user cannot share the plants shared to him by the end user to other users.

### Subsequent procedure


Once the sharing is cancelled, the user to whom a plant is shared cannot view or manage the plant any more.

- The end user cancels the sharing

1. Click the icon  on the operation bar, to enter the sharing interface.

2. Click the icon  on the operation bar, to cancel the sharing.

- The user to whom a plant is shared cancels the sharing

1. Click the icon  in the plant operation area, and a window pops up.

2. Click “Confirm”.

## Plant Publicity

When “Publish plant” is turned on, the plant can be shared to visitors.

### Prerequisites

The end user has the permission of turning on “Publish plant”.

The end user has plants.

### Procedure

1. Click the icon  on the operation bar, to enter the sharing interface.

2. Turn on the “Publish plant” switch, so that visitors can view plant data.

### Subsequent procedure

The end user cancels plant publicity


1. Click the icon  on the operation bar, to enter the sharing interface.

2. Turn off the “Publish plant” switch, so that visitors cannot view plant data.

# Querying Plant

## Querying Plant

---

1. Select plant state and plant type, enter plant name and S/N on the top of the home interface.
2. Click , to view corresponding plants.

# Fault

# Interface Description

## Interface Description

Click “Fault” on the menu bar to enter the fault list interface and view the plant alarm information.



1.Plant list 2. Fault query bar 3. Fault information list 4. Operation bar



### Plant list

Display information on the plants, devices, and measuring points.

### Fault query bar

Users can search corresponding faults by setting corresponding conditions.

Other functions

Parameter	Description
Fault refresh setting	Set refresh time in the upper right corner of the interface, where the minimum interval is 5 minutes, and click  to refresh the fault list.
Batch close	Select multiple faults in the fault list, and click “Batch close” in the upper right corner to close faults in batch.
Fault export	Click the icon  in the upper right corner to export faults within specified time segment, where the exported file is in .xlsx format by default.

### Fault information list

In the fault information area, users can view information such as plant name, alarm type, alarm name, device name, and occurrence time. In addition, users can view fault details and close the faults.

### Plant operation bar

In this area, users can view fault details and close faults.


# Querying Faults

## Querying Faults

---

This section describes how to query faults.


### Procedure

1. Select the fault tab “Active” or “Closed”.
2. Set time segment, where the default time segment is one year.
3. Enter the alarm name and select alarm type.
4. Click  to view the corresponding faults.

# Viewing Fault Details

## Viewing Fault Details

---

1. Click the icon  on the operation bar, to enter the fault detail interface.
2. View basic fault information, such as fault type, source, processing time, and processing opinion.


# Closing Fault

## Closing Fault

---

This section describes how to close faults.

### Procedure

1. Click the icon  on the operation bar, to enter the fault closing interface.
2. Fill in processing opinion.
3. Click “Close fault”.

# Report

## Report

---

View plant statistics reports (daily report, weekly report, monthly report, annual report and overall report); or create self-defined reports.

# Interface Description

## Interface Description

---

Click the menu “Report” to enter the report interface and view report information.



1.Display area 2.Report push configuration

### **Display area**

Content displayed in this area varies with function interfaces.

### **Report push configuration**

The report can be sent to the reserved e-mail box through configuration.

# Custom Report

## Custom Report

---

Users can create self-defined reports according to demands.

### Procedure

1. Click the menu "Report" to enter the "All" tab by default.
2. Click "Custom report" to enter the corresponding interface.
3. Click "Add" and select a report type, a report period, plants and indicators.
4. Click "Save", enter the report name, and click "Confirm", to add the new report to the custom report.

# Statistics Report

## Statistics Report

---


You can view statistics report of a plant, and the report types include daily report, weekly report, monthly report, annual report, and overall report.

The steps of viewing daily report, weekly report, monthly report, annual report, and overall report are the same, and description is given by using the steps of viewing daily report as an example.

### Viewing daily report

1. Click the menu "Report" to enter the "All" tab by default.
2. Click "Statistics reports -> Daily report" to enter the corresponding interface, on which statistics information of the plant on the current day is displayed by default, including today yield, today revenue, etc.
3. Perform the following operations according to actual conditions.

### Viewing report on the specific day

Click the icon  , select the desired date. Corresponding data will be displayed.

### Exporting report

Click "Export", select a desired location, and click "save" to save the report locally.



# Report Push

## Report Push

---

The report can be sent to the reserved e-mail box.

### Procedure


1. Click the menu "Report" to enter the "All" tab by default.
2. Click the icon  in the upper right corner to enter the "Email configuration for receiving report" interface.
3. Click "Add" to enter the e-mail address.
4. Optionally, click the icon  to add several addresses.
5. Select report type and click "Confirm". The added e-mail address information will be displayed on the "Email configuration for receiving report" interface, and the state is "Wait the other party to confirm".
6. You will receive a system e-mail once the e-mail address is added successfully. Click "Accept" in the received e-mail to finish the activation.
7. The state will turn into "Success".

### Subsequent processing

- Modifying the type of report you would like to receive.

Click the icon  to enter the "Edit" interface, select report types, and click "Confirm".

- Deleting e-mail address

Click the icon  on the operation bar and then click "Confirm" on the pop-up window.

# Curve

# Interface Description

## Interface Description

---

Click “Curve” on the menu bar to enter the “Curve” interface and view the curve of the plant and device.



1.Plant list 2.Time range 3.Refresh time 4.Query template 5.Display area



### Plant list

Display information on the plants, devices, and measuring points.

### Time range

Set the time range and time interval.

### Refresh time

The refresh time is 5 min by default (the minimum refresh interval). Tick “Refresh time”, and click the icon  to increase the value or click the icon  to decrease the value.

### Query template

Save query template: save the current search conditions as a template for future using.

Select query template: use the existing query templates.

### Display area


Display the plant or device information, such as curve and report.

# Viewing Curve

## Viewing Curve


---

### Procedure


1. Click “Curve” on the menu bar to enter the corresponding interface.
2. Select parameters of a corresponding device in the plant list to add a parameter curve. The upper display area displays curve within a day by default. The lower part displays parameter list. You can change the curve type and statistical pattern.
3. Optionally, click the icon  in the upper right corner of the interface to display the parameters in the table form. Click “Export”, select a desired location, and click “save” to save the report locally.

### Subsequent processing

- Deleting a single curve

Click the icon  in the parameter list area, to delete the corresponding curve.

- Deleting all curves

Click the icon  in the title bar of the parameter list area, to delete all the curves.

# Saving Query Template

## Saving Query Template

---

Save the current query conditions as a template for future using.

### Procedure

1. Click “Curve” on the menu bar to enter the corresponding interface.
2. Select parameters of a corresponding device in the plant list to add a parameter curve.
3. Optionally, modify time range and time interval.
4. Click “Save query template” and enter the template name.
5. Click “Confirm” to save the current query template.

# Selecting Query Template

## Selecting Query Template

---

Directly use the existing query templates.

### Prerequisites

The system has query templates.

### Procedure

1. Click “Curve” on the menu bar to enter the corresponding interface.
2. Click “Select query template” and click “View” on the operation bar. The system will automatically return to the “Curve” interface and display curves according to the selected template.

# Settings

# Interface Description

## Interface Description

---

Click “Advanced -> Settings” to enter the parameter setting interface, on which you can set device parameters.



1. Plant list
2. Device query bar
3. Operation bar
4. Device information list

### **Plant list**

Display information on the plants, devices, and measuring points.

### **Device query bar**

Users can search for desired devices by setting corresponding conditions.

### **Operation bar**

The operation bar includes buttons such as “Initial grid connection”, “General parameter setting” and “Task list”.

### **Device information list**

In the device information list area, you can view information such as plant name, device name, initial grid-connection state, device S/N, and inverter model. In addition, you can further view inverter parameters and history tasks.


# Querying Device

## Querying Device

---

In the device list area, you can view plant name, device name, device S/N, inverter model, and grid type. In addition, you can further view inverter parameters and history tasks.

1. Select inverter model, country (region), and grid type in the device query area.

2. Click  , to view corresponding devices.

# Initial Grid Connection

## Initial Grid Connection

---

On the initial grid connection interface, you can set parameters for the inverter, such as “Country (region) selection”, “Grid type”, and other parameters related to the specific inverter type.

### Prerequisites

The user has the permission of setting initial grid-connection parameters.

The device supports the initial grid-connection setting.

### Procedure

1. Select desired plants from the left plant list.
2. Select desired plant devices from the device information list.
3. Click “Initial grid connection” to enter the corresponding interface.
4. Select country, grid type, and other related parameters, and then click “Apply settings” on the bottom of the interface.
5. Enter the login password on the pop-up window and enter the setting interface.
6. Enter the task name on the “Settings” interface, select “Instruction valid period”, and click “Confirm”, so that the system generates parameter delivery task. The “Instruction valid period” can be set to 0.5h, 1h, or 72h.  
  
If the delivered instruction has not been executed within the set time, the instruction will turn to be invalid.
7. Automatically enter the “Task list” interface. Click “View” on the operation bar to view the corresponding task. Click “Cancel the task” to cancel the latest parameter setting.

# Command Line Parameters Setup

## Command Line Parameters Setup

---


Users can set parameter address, data type, and set value for the inverter through the command line parameters setup.

### Prerequisites

The user has the permission of command line parameters setup.

The device supports the parameter setting.

### Procedure

1. Select a desired plant from the left plant list.
  2. Select desired plant devices from the device information list.
  3. Click “ -> Command line parameters setup” to enter the corresponding interface.
  4. Click “Add” to fill in parameter address, data type, and set value.
  5. Tick desired instructions and click “Apply settings”.
  6. Enter the login password on the pop-up window and enter the setting interface.
  7. Enter the task name on the “Settings” interface, select “Instruction valid period”, and click “Confirm”, so that the system generates parameter delivery task. The “Instruction valid period” can be set to 0.5h, 1h, or 72h.
- If the delivered instruction has not been executed within the set time, the instruction will turn to be invalid.
8. Automatically enter the “Task list” interface. Click “View” on the operation bar to view the corresponding task. Click “Cancel the task” to cancel the latest parameter setting.

# General Parameter Setting

## General Parameter Setting

---

Users can set specific parameters for the inverter, such as start/stop, power generation compensation, standby time, etc.

### Prerequisites

The user has the permission of general parameter setting.

The device supports the parameter setting.

### Background information

The initial grid-connection setting has been performed on the device.

### Procedure

1. Select a desired plant from the left plant list.
2. Select desired plant devices from the device information list.
3. Click “Common parameter settings” to enter the corresponding interface.
4. Set system parameters/protection parameters/power control parameters.

Energy management parameter is available for energy storage inverters.

5. Click “Apply settings”.
6. Enter the login password on the pop-up window and enter the setting interface.
7. Enter the task name on the “Settings” interface, select “Instruction valid period”, and click “Confirm”, so that the system generates parameter delivery task. The “Instruction valid period” can be set to 0.5h, 1h, or 72h.  
  
If the delivered instruction has not been executed within the set time, the instruction will turn to be invalid.
8. Automatically enter the “Task list” interface. Click “View” on the operation bar to view the corresponding task. Click “Cancel the task” to cancel the latest parameter setting.



# Advanced Parameter Setting

## Advanced Parameter Setting

---

Users can set parameters such as restore default parameter, 10-min over-voltage protection and over-frequency derating.

### Prerequisites


The user has the permission of advanced parameter setting.

The device supports the parameter setting.

### Background information

The initial grid-connection setting has been performed on the device.

### Procedure

1. Select a desired plant from the left plant list.
2. Select desired plant devices from the device information list.
3. Click “ -> Advanced settings” to enter the corresponding interface.
4. Set system parameters/protection parameters/power control parameters.

Energy management parameter and battery parameter are available for energy storage inverters.

5. Click “Apply settings”.
  6. Enter the login password on the pop-up window and enter the setting interface.
  7. Enter the task name on the “Settings” interface, select “Instruction valid period”, and click “Confirm”, so that the system generates parameter delivery task. The “Instruction valid period” can be set to 0.5h, 1h, or 72h.
- If the delivered instruction has not been executed within the set time, the instruction will turn to be invalid.
8. Automatically enter the “Task list” interface. Click “View” on the operation bar to view the corresponding task. Click “Cancel the task” to cancel the latest parameter setting.



# Viewing History Task

## Viewing History Task

---

Users can view parameter setting history for a single device or several devices.

### Procedure

1. Click “Task list” to enter the corresponding interface.
2. Select a time range, enter the task name, and click “Search”, to view the corresponding history tasks.
3. Click the “View” button on the operation bar to view corresponding information, such as execution result, execution instruction, and read-back value.
4. Click “Export” to download the read-back values.

# Firmware Update

## Firmware Update

---

Only distributor/installer has the permission of firmware update.

# Interface Description

## Interface Description

---

Click “Advanced -> Firmware update” to enter the corresponding interface, on which you can upgrade plant software.。



1. Plant list
2. Device query bar
3. Operation bar
4. Device information list

### **Plant List**

You can view the plant information.

### **Device query bar**

Users can search for desired devices according to conditions set.

### **Operation bar**

You can perform firmware update and view history tasks.

### **Device information list**

You can view plant name, device S/N, device type, device model, online state, current version, etc.

# Firmware Update

## Firmware Update

---

On this interface, you can remotely upgrade device software of the plant system.

### Prerequisites

The user has the permission of firmware upgrade.


The device supports the remote upgrade.

The user has got the upgrade file and has saved it locally.

### Procedure

1. Click "Advanced -> Firmware update" to enter the corresponding interface.
2. Select plants from the left plant list. Devices of the selected plants are displayed in the display area.
3. Select desired devices in the device information list area. (Batch selection is supported)

You can upgrade devices of the same type and same model in batch.

4. Optionally, select "Device type", "Device model", and "Device S/N" and click . The interface will display corresponding devices. Select desired devices.

Currently, you can select device S/N in the following two manners:

- Manually enter: enter the device S/N in the "Device S/N" field, where S/Ns are separated by commas.
- Batch import: Click the "Device S/N" field and then "Select file" to import the desired file.

5. Click "Firmware update", after which the "Upload the upgrading package" pops up.
6. Click "Select file" to select the upgrade package and click "Upgrade". The password window pops up.

The upgrade package is the .zip file.

7. Enter the login password and wait for the uploading. You can view history upgrade information by click "View task history".





# Viewing Task History

## Viewing Task History

---

You can view the history update information.

### Procedure

1. Click “Advanced -> Firmware update” to enter the corresponding interface.
2. Click the icon  to enter the corresponding interface.
3. Select the time range, device type, device model, and goal software version, and click  , so that you can view the corresponding history tasks.

# String IV Curve Scan and Diagnosis

## String IV Curve Scan and Diagnosis

---


Only the distributor/installer has the permission of the “string IV curve scan and diagnosis”.

Scan PV module IV curve in online manner, automatically locate faulty PV modules through the diagnostic algorithm analysis, and generate diagnostic reports and O&M advice, thereby greatly improving O&M efficiency and power generation.

# Interface Description

## Interface Description

Click “Advanced -> String IV curve scan and diagnosis” to enter the corresponding interface, on which you can perform unit level scanning and inverter level scanning.



1. Plant list 2. Device list 3 Operation bar

### Plant List

You can view the plant information.

### Device List

You can view unit devices and inverters of the corresponding plant.

### Operation bar

You can view history task and perform related settings.

# Parameter Setting

## Parameter Setting




---


This section describes how to set plant or inverter parameters.

### Prerequisites

The user has the permission of the “string IV curve scan and diagnosis”.

### Procedure

1. Click “Advanced -> String IV curve scan and diagnosis” to enter the corresponding interface.
2. Select the desired plant from the left plant list.
3. Click “Setting” on the operation bar to enter the “IV Intelligent curve analysis” interface. Enter the “Plant parameter setting” interface by default.
3. Perform the following operations if necessary.
  - Set PV module parameters applicable to the whole plant on the “Parameter Setting” interface. After finishing the parameter setting, click “Confirm” to save the operation.
  - Click “Unit parameter setting” and select the desired inverters. Click “Settings” on the operation bar corresponding to the selected inverter, to set parameters for the single inverter. After finishing parameter setting, click “Confirm”.
  - Optionally, click “Unit parameter setting” and select several desired inverters. Click “Batch settings” to set parameters for the several inverters. After finishing parameter setting, click “Confirm”.
  - Click the tab “PV module management”, to add, delete, or view PV module information.
    - Query PV module: enter PV module manufacturer, select module type, and enter module model. Click the icon  to view corresponding PV modules.
    - Add PV modules: click “Add” to enter the corresponding interface. Fill in corresponding information and click “Confirm”.
    - View PV module information: click the icon  in the operation bar to enter the corresponding interface, on which you can view detailed information on the PV modules.
    - Modify PV module information: click the icon  in the operation bar to enter the corresponding interface, on which you can modify the information on the PV modules.

- Delete PV module information: Click the icon  in the operation bar, click “Confirm” on the pop-up window, and click “Confirm” on the prompt window to finish the operation.
- Batch delete: select multiple pieces of PV module information, click “Batch Delete”, and click “Confirm” to finish the operation.

# Advanced Settings




## Advanced Settings

---

### Prerequisites

The user has the advanced permission of “string IV curve scan and diagnosis”.

### Procedure

1. Select the desired plant from the left plant list.
2. Click “Advanced Settings”, to enter the corresponding interface.
3. Perform the following operations if necessary.
  - Query advanced parameter settings: enter parameter and parameter name, and click the icon  , to view the corresponding setting list.
  - Add advanced parameter settings: click “Add” to enter the corresponding interface. Fill in parameter, parameter name, and parameter value, and click “Save”.
  - Modify advanced parameter settings: click the icon  in the operation bar, to enter the add interface, on which you can modify advanced parameter settings. Click “Save” to finish the operation.
  - Delete advanced parameter settings: click the icon  in the operation bar, click “Confirm” on the pop

Original advanced parameters in the system cannot be deleted but modified only.

# IV Intelligent Curve

## IV Intelligent Curve

---

This section describes how to scan IV curve and view the diagnosis analysis.


### Prerequisites

The user has the permission of the “string IV curve scan and diagnosis”.

### Procedure for unit level scan

1. Click “Advanced -> String IV curve scan and diagnosis” to enter the corresponding interface.
2. Select the desired plant from the left plant list.
3. Enter the “Unit level scan” interface by default.
4. Select unit devices and click “Start diagnosis” in the lower right corner.
5. Enter login password on the pop-up window and click “Confirm”.

The system will judge whether the device parameters have been configured. If not, a “Prompt” window will pop up. Click “Confirm” to jump to the corresponding interface and perform parameter settings.

6. After the instruction is delivered successfully, the unit state is changed to “Scanning” and you can view the scanning progress.
7. After the scanning, click “Diagnosis Report” to view the scanning results.
8. The upper part of the interface displays the examination report and the number of abnormal strings. Click the icon  to export diagnosis report. The lower part displays the tab “IV intelligent curve analysis”, on which string information is displayed. Click “View” to enter the “String diagnosis and analysis” interface, on which detailed string information and curves are displayed.

9. Click “IV curve” to view IV curves of all strings.

### Procedure for inverter level scan

1. Click “Advanced -> String IV curve scan and diagnosis” to enter the corresponding interface.
2. Select the desired plant from the left plant list.
3. Enter the “Unit level scan” by default.
4. Click “Inverter level scan” to scan a single inverter or several inverters.

5. Select inverters and click “Start diagnosis” in the lower right corner.

6. See Step 5 to Step 9 in the procedure for unit level scan.


# Viewing Task History

## Viewing Task History

---

You can view the history IV curve scanning.

### Procedure

1. Click “Advanced -> String IV curve scan and diagnosis” to enter the corresponding interface.
2. Click “Task history” to enter the corresponding interface.
3. Select time range and task type, enter task name, and click , so that you can view the corresponding history tasks.

# Failure Plan

## Failure Plan

---

Plan management is managing the running state of the device in the plant system, for example, fault, alarm, and advice.

# Interface Description

## Interface Description

---

Click “Advanced -> Failure plan” to enter the corresponding interface. You can add, modify, and delete (singly or in batch) plan information.



1. Query bar
2. Plan information list
3. Operation bar
- 4 Add and batch deleted

### **Query bar**

Users can search for desired plan information according to conditions set.

### **Plan information list**

Users can view the corresponding plan information.

### **Operation bar**

Modify and delete selected plan information.


### **Add and batch delete**

Add and delete plan information in batch.

# Querying Plan Information

## Querying Plan Information

---

1. Enter the plant or plan name.
2. Click  to view the corresponding plan information.

# Adding Plan Information

## Adding Plan Information

---

This section describes the procedure of adding plan information.

### Prerequisites

The user has the permission of adding plan information.

### Procedure

1. Click “Add” to enter the corresponding interface.
2. Fill in the plan name, select a plant, and tick fault types that you would like to receive.
3. Click “Add” to add the remind person. You can add the remind person in the following two manners:
  - Add e-mail address not registered in the iSolarCloud system:  
  
Click “Custom” to access the “Add to-be-prompted person” window. Fill in the language and name, select remind method, fill in e-mail address and verification code, and click “Confirm”.
  - Add e-mail address already registered in the iSolarCloud system:  
  
Click “Select people” to access the “Add to-be-prompted person” window. Select the desired people and remind method, and click “Confirm”.
4. Click “Confirm” to save the plan configuration.
5. The newly added plan is displayed on the plan management interface after it is added successfully.

# Deleting Plan Information in Batch

## Deleting Plan Information in Batch

---

This section describes the procedure of deleting plans in batch.

### Prerequisites

The user has the permission of deleting plan information in batch.

### Procedure

1. Select several pieces of plan information in the plan list, and click “Batch deleted”.
2. A prompt window pops up.
3. Click “Confirm” to delete the selected plan information in batch.

# Modifying Plan Information

## Modifying Plan Information


---

This section describes the procedure of modifying plan information.

### Prerequisites

The user has the permission of modifying plan information.

### Procedure

1. Click the icon  corresponding to the plan that needs to be modified, to enter the “Modify” interface.
2. Change the plan name and select a desired plant as well as corresponding plan type, such as fault, alarm, and advice. Further, change the remind person and remind method.
3. Click “Confirm” to finish modifying the plan information.

# Deleting Plan Information

## Deleting Plan Information


---

This section describes the procedure of deleting plan information.

### Prerequisites

The user has the permission of deleting plan information.

### Procedure

1. Click the icon  corresponding to the plan that needs to be deleted.
2. A “Prompt” window pops up.
3. Click “Confirm” to delete the plan information.

# Appendix

# Manual Description

## Manual Description

---

The information contained in this document is the property of Sungrow Power Supply Co., Ltd. (referred to as “SUNGROW” hereinafter). Publishing its content, either partially or in full, requires the written permission of SUNGROW. Any internal company copying of the document for the purposes of evaluating the product or its correct implementation is allowed and does not require permission.

All rights reserved including the pictures, symbols, and identifiers used in this manual. Any reproduction or disclosure, even partially, of the contents of this manual is strictly prohibited without prior written authorization of SUNGROW.

The content of the manual will be periodically updated or revised as per the product development. It is probably that there are changes in manuals for the subsequent module edition.

# Contact SUNGROW

## Contact SUNGROW

Should you have any question about this product, please contact us.

China (HQ) Sungrow Power Supply Co., Ltd Hefei +86 551 65327834 service@sungrowpower.com	Australia Sungrow Australia Group Pty. Ltd. Sydney +61 2 9922 1522 service@sungrowpower.com.au
Brazil Sungrow Do Brasil Sao Paulo +55 11 2366 1957 latam.service@sa.sungrowpower.com	France Sungrow France – Siege Social Paris - service.france@sungrow.co
Germany Sungrow Deutschland GmbH München +49 89 324 914 761 service.germany@sungrow.co	Greece Service Partner – Survey Digital - +30 2106044212 service.greece@sungrow.co
India Sungrow (India) Private Limited Gurgaon +91 080 41201350 service@in.sungrowpower.com	Italy Sungrow Italy Milano - service.italy@sungrow.co
Japan Sungrow Japan K.K. Tokyo +81 3 6262 9917 japanservice@jp.sungrowpower.com	Korea Sungrow Power Korea Limited Seoul +82 70 7719 1889 service@kr.sungrowpower.com
Malaysia Sungrow SEA Selangor Darul Ehsan +60 19 897 3360 service@my.sungrowpower.com	Philippines Sungrow Power Supply Co., Ltd Mandaluyong City +63 9173022769 service@ph.sungrowpower.com
Thailand Sungrow Thailand Co., Ltd.	Spain

<p>Bangkok +66 891246053 service@th.sungrowpower.com</p>	<p>Navarra service.spain@sungrow.co</p>
<p>Romania Service Partner - ElereX - +40 241762250 service.romania@sungrow.co</p>	<p>Turkey Sungrow Deutschland GmbH Turkey Istanbul Representative Bureau Istanbul +90 212 731 8883 service.turkey@sungrow.co</p>
<p>UK Sungrow Power UK Ltd. Milton Keynes +44 (0) 0908 414127 service.uk@sungrow.co</p>	<p>U.S.A , Mexico Sungrow USA Corporation Phoenix Arizona +1 833 747 6937 techsupport@sungrow-na.com</p>